



Biosynex™ CryptoPS RDT





1. Unwrap the cassette and place on a flat surface.
2. Pipette **40µL** of CSF into the sample well (S)
3. Add **3 drops** of diluent into the S well
4. Wait **10 minutes**
5. Read the result

Positive

Negative



Invalid



Things to remember:

- Use a new pipette tip and fresh gloves for each test.
- Ensure the pipette volume is set correctly.
- Do not read a result beyond 15 minutes.
- Ensure control line present or else test is invalid.